

Instruction Manual



Colore Pizza Oven

Thank you for purchasing this King Edward product, it has been hand built in the UK using high quality components. This instruction manual will help you get the best out of your purchase. We recommend you make a note of your serial number in case you need it for future reference.

If sold to non UK markets, these instructions can be provided in the appropriate language if required.

Contents

	Packaging	5
	Installation	5
	Health & Safety	5
	Cleaning & Maintenance	ŀ
	Changing the Bulb	5
•	Changing the door seal6	5
	Wiring Instructions for UK Plug4	ŀ
	Trouble Shooting	7
	Warranty	7
	EU Declaration of Conformity	3



Packaging

The packaging your product was delivered in can all be recycled. Please dispose of it responsibly with consideration for the environment. Remove all packaging from inside and outside of the oven before connecting it to the electricity supply.



Installation

- Choose a stable flat work surface with a weight bearing capacity suitable for the product you have purchased.
- Do not site the oven within 200mm (8") of combustible material.
- The exterior of this appliance will get hot during operation, especially the doors and surrounding flange.
- The oven door will be the hottest surface do not site the oven where customers or untrained staff can access the oven door.



• You will require 2 suitable 220-240 volt 13amp sockets to plug your appliance into.



- Do not use a multi adaptor to share this socket as electrical overloading may occur.
- Do not trap the mains flex under the appliance or place it next to hot surfaces, damage to flex is not covered by warranty.
- If the mains flex is damaged, it must be replaced by the manufacturer, their service agent, or a similarly qualified person.



Health & Safety


When using this equipment it is important that you apply industry recognised Health and Safety procedures for electrical cooking equipment and the handling and serving of hot food.

- Always use an oven glove or gauntlet when operating this equipment or removing any type of hot food from it.
- Keep your hands and face away from the main oven door for a few seconds after opening it to give the hot air and steam time to escape safely into the room.
- Under NO circumstances should children come into contact with or operate this appliance.



Instructions for Use

- 1. Connect The oven to the electricity supply and ensure the pizza stone is correctly positioned inside the oven before heating.
- 2. Switch on the rocker stitch and turn the oven temperature knob to the required setting. Set the pizza stone knob to the required temperature, (we recommend 1 to start with) Do not leave the pizza stone setting on FULL.
- 3. When the red neon light goes off (approx. 30 mins) the required temperature has been achieved. You can then load the pizza.




- If cooking frozen pizzas or thicker bases increase the cooking time at a lower temperature.
- Always monitor the oven whilst cooking to avoid burning of product



Wiring Instructions for UK Plug

This appliance must be earthed; any work carried out must be done by a qualified electrician.

- 1. Prepare all 3 wires by stripping back silicone to expose 8mm of bare wire
- 2. Loosen cord grip
- 3. Wire in the sequence: Neutral Live Earth
- 4. Ensure terminal screws are tight
- 5. Always use 13 amp (Brown) fuse
- 6. Tighten cord grip onto cord before replacing cover



General Cooking tips

Fresh pizzas do not require long cooking times as the dough is usually relatively thin and will be chilled or at room temperature. Toppings are usually diced/sliced or pre-cooked and then spread evenly over the surface.

We recommend you set the oven temperature to 300 with the base set to 300, this will cook most fresh pizza in around 3-4 minutes. Obviously no two pizzas are the same and according to the dough you use and the type of toppings applied you will have to experiment within these parameters to get the result you want.

To pan cook a pizza you will require slightly more heat to the base. If you then want to give the pizza a stone cooked finish then remove it from the pan and cook it on the stone base for approximately 30 seconds before serving.

If you want to use semolina flour on the stone while cooking your pizza please use it sparingly and always remove any charred flour or crumbs by brushing or scraping them into the removable crumb tray.



Any foodstuffs such as pasta bakes, lasagne and pies can be baked in the oven in a suitable oven proof container.

For more cooking tips for the ovens please visit our YouTube page and search King Edward Catering Equipment.



Cleaning your oven on a daily basis will help maintain its good looks and prevent stains from setting in.

- 1. Always allow the oven to cool and disconnect it at the socket before cleaning.
- 2. Clean the exterior and interior with warm soapy water and a cloth. Do not use abrasive materials or cleaners on any part.
- 3. There is a removable crumb tray below the main door. Make sure the oven is cold before removing. there is a splatter guard above the top element in the oven that can also be removed.
- 4. Quality oven cleaner can be used to clean the stainless steel interior of the oven.
- 5. Do not submerge this oven in water or use any water jets to clean it.
- 6. Do not clean the pizza stone with any liquid substance. Use a dry cloth once stone is cooled



Changing the Bulb

This oven uses a push-in G9 25 watt, 240volt halogen capsule lamp, these can be readily obtained from most DIY stores. Bulbs are not covered by guarantee.

- 1. Disconnect the oven from the electrical supply.
- 2. Carefully unscrew the glass bulb cover inside the oven.
- 3. Remove the old bulb by pulling away from the connection end.
- 4. Do not touch the new bulb with bare hands, if touched, wipe clean with a cloth and methylated spirit.
- 5. Replace the new bulb by pushing prongs into the relevant holes and reattach the glass lens.



Changing Main Oven Door Seal

- 1. Ensure the oven is switched off.
- 2. Open the main oven door pull the door seal from channels on the oven opening.
- 3. Install the new door seal by pushing the seal into the channels on all 3 sides.



Trouble Shooting

Please refer to the checklist below before you call your supplier to request a service call. You will be charged for a service call if we find that the equipment is not at fault even if it is still within the guarantee period.

If there is no power to the oven i.e. lights are not working and oven is not heating up, check to see:

- 1. Is the oven switched on at the socket?
- 2. Have you turned the main oven dial on?
- 3. Has the fuse blown in the plug?
- 4. Is the trip on the mains board still on?
- 5. Has the mains circuit been overloaded?
- 6. Is the oven the only piece of equipment using the socket?
- 7. Is the mains flex damaged?

For any other operating issues, telephone your supplier or King Edward Catering Equipment, we will attempt to assist you over the telephone if we can.



Warranty

- Your oven has a parts guarantee and labour guarantee for a period of 1 year for UK purchases. The guarantee covers defective parts or workmanship from the time of purchase for a period of 1 year. This does not affect your statutory rights.
- Bulbs, fuses, door seal, damage to mains lead, glass parts and cordierite stone are not covered by guarantee. Faults arising from incorrect maintenance or cleaning and the fitting of unspecified parts are also excluded.
- We respond to all service calls promptly but depending on Geographical limits and other limitations beyond our control we may not be able to attend within 24 hours.
- Wherever possible we will attempt to establish the nature of the fault over the telephone and may decide to send parts directly to site.
- In exceptional circumstances we may require the equipment back to our factory for repair, in these cases please allow 4 days from collection to delivery.
- Please ensure that the equipment is completely cooled and in an area where it can be worked on from all sides before the engineer's visit.
- This equipment must not be disposed of along with household waste. Its high metal content makes it ideal for recycling and it can be disposed of through a recognised disposal system.

EU Declaration of Conformity

The manufacturer of the products covered by this Declaration is

Monarch Products (Marketing) Ltd
t/a King Edward Catering Equipment
Porthouse Ind Est
Bromyard
Herefordshire
HR7 4NS
oven@kingedward.co.uk

The Directives covered by this Declaration

Low Voltage Directive 2014/35/EU EMC Directive 2014/30/EU RoHS Restriction of Hazardous Substances-Directive-2011/65/EU Waste Electrical and Electronic Equipment Directive-2012/19/EU



The basis on which Conformity is being declared

The manufacturer hereby declares under his sole responsibility that the products identified above comply with the protection requirements of the EMC and LVD directives and that the following standards have been applied:

EN 60335-1:2012 + AC:2014 + A11:2014 EN 60335-2-42:2003 + A11:2012/BS EN60335-2-42:2003+A11:2012

The technical documentation required to demonstrate that the product meets the requirements of EMC and LVD directives has been compiled and is available for inspection by the relevant enforcement authorities.

Signed: Paul Wrighton, Managing Director

Date: 01/01/2018

The attention of the specifier, purchaser installer or user is drawn to special measures and limitations to use which must be observed when these products are taken into service to maintain compliance with the above directives. Details of these special measures and limitations to use are available on request and also contained in product manuals.

As an independent manufacturer we can often adapt our designs and finish to suit specific requirements, please contact us if you would like to find out more about what we can do.



King Edward Catering Equipment Porthouse Industrial Estate, Bromyard, Herefordshire, HR7 4NS

> 01885 489200 oven@kingedward.co.uk www.kingedward.co.uk