


HOW TO CHANGE YOUR BATTERY

GREASEPAK

manufactured by **MECHLINE**

GREASEPAK **Mk 1** & **Mk 2** MODULES




ABOUT YOUR GREASEPAK REPLACEMENT BATTERY



This battery pack is for use only with Mechline's GreasePak battery operated, biological drain maintenance systems.


- **Product code:** GP-BP
- **Type:** Alkaline
- **Voltage:** 6V (Nominal)
- **Manufacture date:** *This will be printed on the battery pack label.*
- **DO NOT:** Short circuit, disassemble, incinerate or charge this battery pack.
- **DO:** Observe correct polarity
- **Service life:** Approximately 12-24 months
- **Warranty:** Battery packs are basic 'consumable' goods and not subject to warranty.

This leaflet contains an easy step-by-step guide on how to change your battery. The section you need will depend on which dosing module you have installed.



Does your GreasePak module look like this?



See **page 2** for how to change your battery.




Does your GreasePak module look like this?

See **page 3** for how to change your battery.


Page 2. BATTERY CHANGE INSTRUCTIONS FOR - **Mk 1 MODEL** →




- 2.1 Open the dosing unit door and remove the fluid box.
- 2.2 Carefully remove the electronics cover and store safely.



- 2.3 Unplug the battery pack connector on the PCB and carefully remove the old battery pack from the mounting bracket.
- 2.4 Fit the replacement battery pack and plug into the PCB.




- 2.5 Hang the fluid box in the dispenser. Follow the box instructions to connect.
- 2.6 Press the **RESET** button on the PCB.




- 2.7 **PRESS & HOLD** the **CLOCK / START / VOLUME** buttons one at a time to set desired values.
 - CLOCK** = Time now (set to nearest hour using a 24hr clock)
 - START** = Dosing time (factory set at 01:00 but ideally set one hour after kitchen stops using water)
 - VOLUME** = Dosing volume (factory set at level 2)
- 2.8 Press **OPEN** then **CLOSE** buttons on the PCB. Listen for audible 'click' to confirm new battery is working. Green fluid should flow when **OPEN** is pushed and stop when **CLOSE** is pushed.

IMPORTANT: Press **CLOSE** last.




- 2.9 Refit the electronics cover. Check the fluid box can move up and down freely. Close the dosing unit door.






Page 3. BATTERY CHANGE INSTRUCTIONS FOR - **Mk 2 MODEL** →



Fluid pack

Front cover


- 3.1 Open the dosing unit door and remove the fluid box.
- 3.2 Remove the 2 screws that secure the front cover. Carefully pull the front cover downwards to remove.



Old Battery pack

Replacement Battery pack


- 3.3 Unplug the battery pack connector on the PCB and carefully remove the old battery pack from the mounting bracket. *NB: If transit plastic tie is still in place, either cut or pull off to remove. There is no need to replace.*
- 3.4 Fit the replacement battery pack and plug into the PCB.




Fluid pack

PCB

- 3.5 Hang the fluid box in the dispenser. Follow the box instructions to connect.
- 3.6 Press the **RESET** button on the PCB.



- 3.7 **PRESS & HOLD** the **CLOCK / START / VOLUME** buttons one at a time to set desired values.
CLOCK = Time now (set to nearest hour using a 24hr clock)
START = Dosing time (factory set at 01:00 but ideally set one hour after kitchen stops using water)
VOLUME = Dosing volume (factory set at level 2)
- 3.8 Press **OPEN** then **CLOSE** buttons on the PCB. Listen for audible 'click' to confirm new battery is working. Green fluid should flow when **OPEN** is pushed and stop when **CLOSE** is pushed.
IMPORTANT: Press **CLOSE** last.



- 3.9 Refit the front cover and secure with 2 fixing screws. Close the dosing unit door.





MECHLINE DEVELOPMENTS LIMITED | Telephone: +44 (0)1908 261511 | Email: info@mechline.com | Web: www.mechline.com

©2017 All rights reserved. All material on these pages, including and without limitation text, logos, icons, photographs and all other artwork, is copyright material of Mechline Developments Ltd, unless otherwise stated. Commercial use of this material may only be made with the express, prior, written permission of Mechline. This includes material provided by any third party, including material obtained through links to other sites from Mechline's pages or its affiliates and commercial associates. Material and information included are correct at time of print. Intending buyers and users must satisfy themselves as to the suitability and safety of the products for their particular purposes and duties. Dimensions shown in mm unless otherwise stated. Product accreditation may not apply to all products in the relevant range. Please contact Mechline to confirm. Unless otherwise stated, all products carry a warranty of twelve (12) months against manufacturing defect or workmanship on parts with no inclusion for labour or site attendance. (GPC050)