

Stainless Steel Counter






Installation, Operation & Maintenance Manual


(HC Gas R290 used)

SET2 DRAWER ASSEMBY GUIDE



Page 2

SET 3 DRAWER ASSEMBLY GUIDE



Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product. Consult Local and National Standards to comply with The following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use this appliance to store medical supplies.
- DO NOT use electrical appliances inside the appliance. (e.g. heaters, ice-cream makers etc.)
- DO NOT stand or support yourself on the base, drawers or doors.
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- Bottles that contain a high percentage of alcohol must be sealed and placed vertically in the refrigerator.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packing away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an agent or a recommended qualified technician in order to avoid a hazard.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your product.

Pack Contents

The following is included:

- Refrigerator or Freezer
- Shelf guides (2 per door)
- Shelves (1 per door)
- Instruction manual

We pride ourselves on quality and service, ensuring that at the time of packing the contents are supplied fully functional and free of damage. Should you find any damage as a result of transit, please contact your dealer Note: Before using the appliance for the first time, clean the shelves and interior with soapy water, thoroughly dry afterwards.

3. Set the brakes on the castors to keep the appliance in position OR level the appliance by adjusting the screw feet.

Fitting the Shelves

- 1. Place one set of shelf guides on either side of the cabinet at the desired height.
- 2. Slide the shelf into place.
- 3. Repeat for the remaining shelves.

Note: This is vital for ensuring correct drainage of condensation.

Operation

Storing Food

To get the best result from your appliance, follow these instructions:

- Only store foodstuffs in the appliance when it has reached the correct operating temperature.
- Do not place hot food or liquid inside the appliance.
- All food must becovered including sauces.
- Do not overload each shelf allow sufficient space to allow for air movement around the products.
- Do not obstruct the fans inside the appliance.
- Avoid opening the doors for prolonged periods of time.

Turn on

- 1. Close the door(s) of the appliance.
- 2. Ensure the power switch is set to [O] and turn on at the socket.
- 3. Switch on the power [I]. The current temperature within the the appliance is displayed.

Adjusting the Set Temperature

- 1. Press and hold the set button for 3 seconds till the C led starts blinking with the current set temperature shown
- 2. Use the arrow keys to adjust to the required set temperature setting.
- 3. Press the set key to store, then leave for approx. 5 secs till the display shows the cabinet temperature, the cabinet will then cool down to the new set temperature.

NOTE! The temperature shown on the display will fluctuate during normal use as the unit regulates the cabinet temperature.

Manual Defrost

The appliance will automatically run a defrost cycle every six hours.

immediately.

Installation

Note: If the unit has not been stored or move in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.

- Remove the appliance from the packaging. Make sure, that all protective plastic film and coatings are thoroughly removed from all surfaces.
- Maintain a distance of 20cm (7 inches) between the unit and walls or other objects for ventilation increase this distance if the obstacle is a heat source.
- Ensure the ambient temperature is within the design range of the cabinet, avoid locations below 15 degrees C.
 Beware of enclosed rooms with other refrigeration equipment as additional ventilation may be required.

Note: The cycle starts from the time the appliance is initially powered up.

To manually defrost the appliance:

- 1. Press and hold the DEFROST button for 5 seconds.
- 2. The defrost cycle will start immediately and the Defrost LEDilluminates. The defrost will last a maximum of 30 minutes

Note: Starting a manual defrost also resets the automatic defrost timer.

3. The next automatic defrost will start six hours after the manual defrost has finished.

Cleaning, Care & Maintenance

- Switch off and disconnect from the power supply before cleaning.
- Clean the interior of the appliance as often as possible.
- Do not use abrasive or corrosive cleaning agents or sprays. These can leave harmful residues.
- Clean the door seal with warm water with a mild detergent only.
- Always wipe dry after cleaning.Stainless steel cleaner can be applied to exterior surfaces to preserve the finish.
- Take care when cleaning the rear of the appliance. Sharp edges can cut.

•An agent or qualified technician must carry out repairs if required.

Cleaning the Condenser

Periodically cleaning the condenser can extend the life of theappliance. We recommend that our agent or qualified technician clean the clean the condenser.

Troubleshooting

If your appliance develops a fault, please check the following table before making a call to your retailer.

Fault	Probable Cause	Action		
	The unit is not switch on	Check the unit is plugged in correctly and switched on		
	Plug and lead are damaged	Call your agent or qualified technician		
The appliance is not working	Fuse in the plug has blown	Replace the fuse		
	Power supply	Check power supply		
	Internal wiring fault	Call your agent or qualified technician		
The appliance turns on, but the temperature is too high/low	Too much ice on the evaporator	Defrost the appliance		
	Condenser blocked with dust	Call your agent or qualified technician		
	Doors are not shut properly	Check doors are shut and seals are not damaged		
	Appliance is located near a heat source or air flow to the condenser is being interrupted	Move the refrigerator to a more suitable location		
	Ambient temperature is too high	Increase ventilation or move appliance to a cooler position		
	Unsuitable foodstuffs are being stored in the appliance	Remove any excessive hot foodstuffs or blockages to the fan		
	Appliance is overloaded	Reduce the amount of food stored in the appliance		
The appliance is leaking water	The appliance is not properly levelled	Adjust the screw feet to level the appliance(If applicable)		
	The discharge outside is blocked	Clear the discharge outlet		
	Movement of water to the drain is obstructed	Clear the floor of the appliance (if applicable)		
	The water container is damaged	Call your agent or qualified technician		
	The drip tray is over flowing	Empty the drip tray (if applicable)		
	Loose nut/screw	Check and tighten all nuts and screws		

The appliance is unusually	Loose nut/screw	Check and tighten all nuts and screws		
loud	The appliance has not been installed in	Check installation position and change if necessary		
	a level or stable position	Check installation position and change if necessary		

Technical Specifications(R290)

Model	Voltage	Power	Current	Temperature	Capacity	Dimensions	Weight
		(W)	(A)	Range(°C)	(litres)	HxWxD(mm)	(kg)
BZ-HBC2XX	220~240V/50Hz	215	1.3	+2~+8	282	950x1360x700	104
BZ-HBC3XX	220~240V/50Hz	230	1.3	+2~+8	417	950x1795x700	134
BZ-HBC4XX	220~240V/50Hz	345	2.0	+2~+8	553	950x2230x700	165
BZ-HBC2CRXX	220~240V/50Hz	215	1.3	+2~+8	282	950x1360x700	104
BZ-HBC3CRXX	220~240V/50Hz	230	1.3	+2~+8	417	950x1795x700	134
BZ-HBC4CRXX	220~240V/50Hz	345	2.0	+2~+8	553	950x2230x700	165
BZ-LBC2XX	220~240V/50Hz	520	3.2	-18~-22	282	950x1360x700	109
BZ-LBC3XX	220~240V/50Hz	560	3.4	-18~-22	417	950x1795x700	159
BZ-LBC4XX	220~240V/50Hz	650	4.0	-18~-22	553	950x2230x700	175
BZ-HBC2SLXX	220~240V/50Hz	220	1.3	+2~+8	228	850x1360x600	94
BZ-HBC3SLXX	220~240V/50Hz	230	1.3	+2~+8	339	850x1795x600	115
BZ-HBC4SLXX	220~240V/50Hz	345	2.0	+2~+8	449	850x2230x600	140
BZ-LBC2SLXX	220~240V/50Hz	520	3.2	-18~-22	228	850x1360x600	92
BZ-LBC3SLXX	220~240V/50Hz	560	3.4	-18~-22	339	850x1795x600	114
BZ-LBC4SLXX	220~240V/50Hz	650	4.0	-18~-22	449	850x2230x600	147
BZ-SNC2XX	220~240V/50Hz	215	1.3	+2~+8	214	650x1360x700	87
BZ-SNC3XX	220~240V/50Hz	230	1.3	+2~+8	317	650x1795x700	107
BZ-SNC4XX	220~240V/50Hz	345	2.0	+2~+8	420	650x2230x700	135
BZ-HBC2ENXX	220~240V/50Hz	320	1.9	+2~+8	282	1085x1360x700	97
BZ-HBC3ENXX	220~240V/50Hz	320	1.9	+2~+8	417	1085x1795x700	130

Electrical Wiring

Appliances are supplied with a 3 pin, moulded, BS1363 plug and lead, with a 13 amp fuse as standard. The plug is to be connected to a suitable mains socket. Appliances are wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E
- All appliances must be earthed, using a dedicated earthing circuit.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Pentland Wholesale Ltd, Blizzard house, Unit17 Walker Park Industrial Estate, Walker Road, Blackburn,

Lancs, BB1 2QE. Tel: 01254 614444, <u>www.pentlandwholesale.co.uk</u>

R290 refrigerant is used for this equipment.



Caution!

Consult repair manual/owner's guide before attempting to install or service this product. All safety precautions must be followed. Dispose of properly in accordance with federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.

Danger!

Risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

Disposal



EU regulations require refrigeration product to be disposed of by specialist companies who remove or recycle all glasses, metal and plastic components.

Consult your local waste collection authority regarding disposal of your appliance. Local authorities are not obliged to dispose of commercial refrigeration equipment but may be able to offer advice on how to dispose of the equipment locally. All packaging materials should be disposed of in an environmentally friendly way. The cardboard may be used as scrap paper. The protective foil and the foam cushions are CFC-free.

Do not allow children to play with the packaging and destroy plastic gags safely.



Environmental protection

Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collectioncenters (if available).

Compliance

Parts have undergone strict product testing in order to comply with regulatory standards and specification set by international, independent, and federal authorities.

Products have been approved to carry the following symbol:

CE