

Troubleshooting Guide - With the appliance unplugged and cool.

Unit not working / dead	Check/replace the plug fuse.
	Check socket and ring main are working and switched on.
	Check cable and plug for condition.
Uneven toasting	Check settings are correct. Selecting bun only toasts one side
	Check unit is not in power saver mode
	Ensure bread type and thickness is consistent.
	One or more elements may need to be replaced
	Different bread types require different settings
Unit is smoking	<i>With the appliance unplugged and cool.</i>
	Empty and clean crumb tray.
	Ensure there is no trapped bread, crumbs or food debris
	If smoking persists, after cleaning, call suitable qualified service engineer to inspect
Element needs replacing	To be carried out by suitably qualified personnel.
	Elements are not covered under manufacturer warranty.
Toast is discharging to wrong side	Adjust the rear discharge door in accordance with the manufacturer instructions.
Unit warmup time	15 to 20 minutes