

How to use an Internal Water Softener

FILLING THE SALT POT

- The low salt light will come on to warn you when the salt pot is empty.
- Unscrew the salt container lid located inside the wash tank and fill with **GRANULAR CATERING SALT**.
- The salt container will approximately regenerate four regeneration cycles and hold 500g of salt.
- (DO NOT OVER SPILL) fill to approximately 1 inch below the top of the salt pot.
- Replace and secure salt pot lid.

REGENERATION CYCLE

The regeneration cycle should be started at the end of the day after the machine has been in use.

- Remove the Drain plug from the wash tank.
- The wash tank will now empty.
- Turn the machine off via the power switch on the unit (NOT VIA THE PLUG SOCKET).
- Close the door/pull down the hood.
- Press the regeneration button and hold for a few seconds until the regeneration light comes on.
- The regeneration of the water softener will take around 20 minutes this process will be fully automatic.
- The water regeneration light will go out and the machine will switch off automatically.
- Remember to re insert the drain plug before re filling the machine.

MEDIUM-WATER HARDNESS MAY REQUIRE FOUR REGENERATIONS A WEEK.

MEDIUM TO HARD-WATER HARDNESS MAY REQUIRE DAILY REGENERATION.

