







Exploded diagram and spare parts list (DR826)

Machine	Explode	Code	Description
DR826 Buffalo Kamado Style Barbeque – 22"	1	AJ370	Top Vent
DR826 Buffalo Kamado Style Barbeque – 22"	2		Ceramic Doom Top
DR826 Buffalo Kamado Style Barbeque – 22"	3		Top Ring
DR826 Buffalo Kamado Style Barbeque – 22"	4	AJ371	Fire Bowl
DR826 Buffalo Kamado Style Barbeque – 22"	5		Bottom Ring
DR826 Buffalo Kamado Style Barbeque – 22"	5.1	AJ372	Right Front Side Shelf Bracket
DR826 Buffalo Kamado Style Barbeque – 22"	5.2		Right Back Side Shelf Bracket
DR826 Buffalo Kamado Style Barbeque – 22"	5.3		Left Front Side Shelf Bracket
DR826 Buffalo Kamado Style Barbeque – 22"	5.4		Left Back Side Shelf Bracket
DR826 Buffalo Kamado Style Barbeque – 22"	6	AJ373	Wood Shelves
DR826 Buffalo Kamado Style Barbeque – 22"	7	AJ374	Charcoal Grate
DR826 Buffalo Kamado Style Barbeque – 22"	8		Ceramic Doom Bottom
DR826 Buffalo Kamado Style Barbeque – 22"	9	AJ375	Tubular Legs(*4)Straight
DR826 Buffalo Kamado Style Barbeque – 22"	10		X Leg Connector
DR826 Buffalo Kamado Style Barbeque – 22"	11	AJ376	Thermometer
DR826 Buffalo Kamado Style Barbeque – 22"	12	AJ377	Handle
DR826 Buffalo Kamado Style Barbeque – 22"	13	AJ378	Cooking Grid
DR826 Buffalo Kamado Style Barbeque – 22"	14	AJ379	Complete Castors (set 4)
DR826 Buffalo Kamado Style Barbeque – 22"	15	AJ380	Felt Gasket
DR826 Buffalo Kamado Style Barbeque – 22"	16		Bottom Draft Door Frame
DR826 Buffalo Kamado Style Barbeque – 22"	17		Bottom Draft Door