





























Exploded diagram and spare parts list












GF422



Machine	Explod	Code	Description
Waring Blender Variable Speed - 4Ltr	1	AE726	Outer Lid /polycarbonate for hot blending
Waring Blender Variable Speed - 4Ltr	2	N206	Gasket /plastic outer lid
Waring Blender Variable Speed - 4Ltr	3	AE727	Baffle Cup for hot blending lid
Waring Blender Variable Speed - 4Ltr	4	WA015	Cap Nut
Waring Blender Variable Speed - 4Ltr	5		Washer /flat 2 Req.'d
Waring Blender Variable Speed - 4Ltr	6	WA272	Blade
Waring Blender Variable Speed - 4Ltr	7		"O" Ring
Waring Blender Variable Speed - 4Ltr	8		Bearing Cap
Waring Blender Variable Speed - 4Ltr	9		"V" Ring /small
Waring Blender Variable Speed - 4Ltr	10		Bearing Holder
Waring Blender Variable Speed - 4Ltr	11	WA052	Washer
Waring Blender Variable Speed - 4Ltr	12	WA231	Bearing 2 Req.'d
Waring Blender Variable Speed - 4Ltr	13		Spacer
Waring Blender Variable Speed - 4Ltr	14		Spring Washer
Waring Blender Variable Speed - 4Ltr	15		Retaining Ring
Waring Blender Variable Speed - 4Ltr	16		"V" Ring /large
Waring Blender Variable Speed - 4Ltr	17		Drive Shaft
Waring Blender Variable Speed - 4Ltr	18	WA310	Key
Waring Blender Variable Speed - 4Ltr	19	AE728	Cover Insert
Waring Blender Variable Speed - 4Ltr	20	AE729	Outer Lid
Waring Blender Variable Speed - 4Ltr	21		Latch Wire 3 Req.'d
Waring Blender Variable Speed - 4Ltr	22		Bracket Assy. /spot welded to container 3 Req.'d
Waring Blender Variable Speed - 4Ltr		WA460	Double Handle Container
	23		Double Handle Container with Guard (older units)
Waring Blender Variable Speed - 4Ltr	24	AB760	Blending Assy. /complete
Waring Blender Variable Speed - 4Ltr	25	WA053	Gasket /container base
Waring Blender Variable Speed - 4Ltr	26	AE730	Container Support /container base
Waring Blender Variable Speed - 4Ltr	27	WA075	Lock Nut
Waring Blender Variable Speed - 4Ltr	28	AE731	Coupling
Waring Blender Variable Speed - 4Ltr	29	AE732	Jar Pad
Waring Blender Variable Speed - 4Ltr			Top Housing
	30		Top Housing (older units)
Waring Blender Variable Speed - 4Ltr	31	AE733	Control Panel Assy.
Waring Blender Variable Speed - 4Ltr	32		Control Panel Rear
Waring Blender Variable Speed - 4Ltr	33		Screw 4 Req.'d
Waring Blender Variable Speed - 4Ltr	34		Control Panel Baffle
Waring Blender Variable Speed - 4Ltr	35	WA017	Washer 4 Req.'d
Waring Blender Variable Speed - 4Ltr	36		Screw 4 Req.'d
Waring Blender Variable Speed - 4Ltr	37	AE734	Motor with Sensor
Waring Blender Variable Speed - 4Ltr	38		Screen
Waring Blender Variable Speed - 4Ltr	39		Screw 6 Req.'d
Waring Blender Variable Speed - 4Ltr	40		Cable Tie 6 Req.'d
Waring Blender Variable Speed - 4Ltr	41	AE735	Baffle
Waring Blender Variable Speed - 4Ltr	42	AE736	Filter & Bracket Assy.
			Filter & Bracket Assy. (older units)
Waring Blender Variable Speed - 4Ltr	43		Screw 3 Req.'d
Waring Blender Variable Speed - 4Ltr	44		Brown Lead
Waring Blender Variable Speed - 4Ltr	45		Blue Lead
Waring Blender Variable Speed - 4Ltr	46		Green-Yellow Lead /ground

## Exploded diagram and spare parts list

GF422

Waring Blender Variable Speed - 4Ltr	47		Strain Relief
Waring Blender Variable Speed - 4Ltr			Strain Relief (older units)
Waring Blender Variable Speed - 4Ltr	48		Cordset with Strain Relief
Waring Blender Variable Speed - 4Ltr			Cord Set (older units)
Waring Blender Variable Speed - 4Ltr	49		Washer /ground 2 Req.'d
Waring Blender Variable Speed - 4Ltr	50		Screw /ground 2 Req.'d
Waring Blender Variable Speed - 4Ltr	51		Bottom Housing
Waring Blender Variable Speed - 4Ltr	52		Washer 4 Req.'d
Waring Blender Variable Speed - 4Ltr	53		Screw 4 Req.'d
Waring Blender Variable Speed - 4Ltr	54	AE737	Foot 4 Req.'d
Waring Blender Variable Speed - 4Ltr	55		Washer 4 Req.'d
Waring Blender Variable Speed - 4Ltr	56		Screw 4 Req.'d
Waring Blender Variable Speed - 4Ltr	02738	AE738	Brush & Spring Assy.