

AD10 Food Mix Exploded diagram Parts List

serial No.	name	serial No.	name
1	worm gear	50	planet gear
2	ring seal	51	bearing
3	axle bearing	52	bearing
4	rotor	53	falt key
5	motor stator	54	planet bearing
6	centrifugal starter	55	taper bolt
7	screw m4*10	56	fork guide bar
8	axle bearing	57	fork
9	axle bearing seat	58	fork with top-selling
10	fan blade	59	fork with spring
11	bearing	60	fork with nut
12	input shaft	61	speed core
13	flat key	62	steel ball
14	flat key	63	spring stalls
15	flat key	64	Variable speed controller handle
16	input shaft gear	65	Transmission Block
17	input shaft sleeve	66	screw
18	worm gear	67	axis with snap spring
19	washer	68	box
20	under gear	69	Within the ring gear
21	axis with snap spring	70	screw
22	bearing	71	Protection Net Block
23	bearing	72	Protection Net
24	ratchet plate	73	hook
25	Outer Ring	74	Shoot
26	Inside the star wheels	75	ball
27	Roller	76	charging basket
28	Roller Spring	77	charging basket block
29	clutch gear up	78	pressing handle
30	output shaft gear sets	79	pressing handle inner jacket
31	output shaft clutch	80	charging basket locating pin
32	central shaft	81	spring swasher
33	flat key	82	nut
34	flat key	83	colum
35	flat key	84	screw
36	output shaft gear sets	85	Outside the hexagon screw
37	clutch gear	86	pressure plate
38	gear ring	87	base
39	bearing	88	fixed sleeve
40	o-ring	89	screw
41	bearing block	90	joystick
42	oil seal	91	lifter screw
43	seal sleeve	92	pin bolt
44	swivel base	93	cotter pin
45	flat pad	94	drag bar
46	spring washer	95	nut
47	nut	96	increase the level pad
48	Outside the hexagon screw	97	compression spring
49	increase the plain washer	98	back air hood

V.Stucture and name of the part

10K /15K

