




Machine	Explode	Code	Description
Rowlett Esprit 2 Slot Toaster	1		Espr-2 Body
Rowlett Esprit 2 Slot Toaster	2		Front Panel-2
Rowlett Esprit 2 Slot Toaster	3		Inner Assy-2
Rowlett Esprit 2 Slot Toaster	4		Heat Shield Assy-2
Rowlett Esprit 2 Slot Toaster	5		Finger Bar-2
Rowlett Esprit 2 Slot Toaster	6		Back Panel-2
Rowlett Esprit 2 Slot Toaster	7		Fixed Plate-2
Rowlett Esprit 2 Slot Toaster	8	AK221	Power Cord
Rowlett Esprit 2 Slot Toaster	9		Power Cord Buckle
Rowlett Esprit 2 Slot Toaster	10		Wire Bushing
Rowlett Esprit 2 Slot Toaster	11	AK222	Fuse Holder
Rowlett Esprit 2 Slot Toaster	12		Fuse
Rowlett Esprit 2 Slot Toaster	13	AK223	Thermostat Cut Out
Rowlett Esprit 2 Slot Toaster	14	AK225	Indicator
Rowlett Esprit 2 Slot Toaster	15	AK239	Timer
Rowlett Esprit 2 Slot Toaster	16	AK240	Timer Knob
Rowlett Esprit 2 Slot Toaster	17		Base Plate
Rowlett Esprit 2 Slot Toaster	18	AK235	Crumb Tray
Rowlett Esprit 2 Slot Toaster	19		Screw/Nut
Rowlett Esprit 2 Slot Toaster	20	AK241	Rubber Feet (set 4)
Rowlett Esprit 2 Slot Toaster	21	AK230	Nut
Rowlett Esprit 2 Slot Toaster	22		Spring
Rowlett Esprit 2 Slot Toaster	23		Ejectorbar
Rowlett Esprit 2 Slot Toaster	24		Sphere Knob
Rowlett Esprit 2 Slot Toaster	25		Guard Wire
Rowlett Esprit 2 Slot Toaster	26	AK231	End Element 310W
Rowlett Esprit 2 Slot Toaster	27	AK232	Middle Element 400W
Rowlett Esprit 2 Slot Toaster	28	AK233	Element Link
Rowlett Esprit 2 Slot Toaster	29		Casting Chrome for CH177
Rowlett Esprit 2 Slot Toaster	29		Casting White for CH178
Rowlett Esprit 2 Slot Toaster	29		Casting Jet Black for CH179
Rowlett Esprit 2 Slot Toaster	29		Casting Traffic Red for CH180
Rowlett Esprit 2 Slot Toaster	30		Casting Chrome for CH177
Rowlett Esprit 2 Slot Toaster	30		Casting White for CH178
Rowlett Esprit 2 Slot Toaster	30		Casting Jet Black for CH179
Rowlett Esprit 2 Slot Toaster	30		Casting Traffic Red for CH180
Rowlett Esprit 2 Slot Toaster	32	AL132	3 Position Selector
Rowlett Esprit 2 Slot Toaster	33	AL133	Selector Knob
Rowlett Esprit 2 Slot Toaster	N/A	AL994	Side & Middle Elements
Rowlett Esprit 2 Slot Toaster	N/A	FS746	Sandwich Cage (Pack of 2)