

HEA754 / HEF573

Electric Griddle



This is an attended appliance

Troubleshooting Guide - With the appliance unplugged, cool and clean.

Unit not working / dead	Check/replace the plug fuse.
	Check socket and ring main are working and switched on.
	Check power cord and plug for condition
Unit not reaching temperature	Thermostat may need to be replaced - contact approved service agent
	Element may need replacing - contact approved service agent
Indicator light is not illuminated	Power indicator light may need to be replaced
Griddle is heating	
Indicator light is illuminated	Check temperature setting dial
Griddle is not heating	Element may need replacing - contact approved service agent
	Thermostat may need to be replaced - contact approved service agent
Unit is slow to warmup	Element may need replacing - contact approved service agent
	Clean cooking surface
Cooking surface is flaking	Carbonized build up on cooking plate, clean appliance thoroughly