


Exploded diagram and spare parts list


































GF439



Machine	Explode	Code	Description
Buffalo Chamber Vacuum Pack Machine	1		M6 Stainless Steel Screw
Buffalo Chamber Vacuum Pack Machine	2		Handle
Buffalo Chamber Vacuum Pack Machine	3		M6 Stainless Steel Nut
Buffalo Chamber Vacuum Pack Machine	4	AE931	Heat-sealing Foam
Buffalo Chamber Vacuum Pack Machine	5		Seal Bar (assembly)
Buffalo Chamber Vacuum Pack Machine	6		Clamp Fixing-spring
Buffalo Chamber Vacuum Pack Machine	7		Clamp

Exploded diagram and spare parts list

GF439

Buffalo Chamber Vacuum Pack Machine	8		Connector for Inlet Valve
Buffalo Chamber Vacuum Pack Machine	9		L Shaped Connector
Buffalo Chamber Vacuum Pack Machine	10		Piston (assembly)
Buffalo Chamber Vacuum Pack Machine	12-17	AE935	Air inlet/ outlet valve & Copper connector
Buffalo Chamber Vacuum Pack Machine	18,18P		Motor
Buffalo Chamber Vacuum Pack Machine	11		T Shaped Connector
Buffalo Chamber Vacuum Pack Machine	19		Rubber Pad
Buffalo Chamber Vacuum Pack Machine	20		Main PCB
Buffalo Chamber Vacuum Pack Machine	21		Insulating Strip for PCB
Buffalo Chamber Vacuum Pack Machine	22		Bottom Board
Buffalo Chamber Vacuum Pack Machine	23		Signal wire
Buffalo Chamber Vacuum Pack Machine	24		Rubber Foot
Buffalo Chamber Vacuum Pack Machine	25	AE932	Control Board (assembly)
Buffalo Chamber Vacuum Pack Machine	26		Mounting Plate for Control Panel
Buffalo Chamber Vacuum Pack Machine	27		Pressure Gauge
Buffalo Chamber Vacuum Pack Machine	28		Power Switch
Buffalo Chamber Vacuum Pack Machine	29		Machine Body
Buffalo Chamber Vacuum Pack Machine	30		Power cord
Buffalo Chamber Vacuum Pack Machine	31		Plug
Buffalo Chamber Vacuum Pack Machine	32		Connecting Board
Buffalo Chamber Vacuum Pack Machine	33		Back Panel
Buffalo Chamber Vacuum Pack Machine	34		Connector for Power Cord
Buffalo Chamber Vacuum Pack Machine	35	AE934	Valve
Buffalo Chamber Vacuum Pack Machine	36		Micro Switch Mount
Buffalo Chamber Vacuum Pack Machine	37		Micro Switch
Buffalo Chamber Vacuum Pack Machine	38		Hinge
Buffalo Chamber Vacuum Pack Machine	39		M5 Stainless Steel Nut
Buffalo Chamber Vacuum Pack Machine	40		Pneumatic Arm
Buffalo Chamber Vacuum Pack Machine	41		Right Spring Fixing Plate
Buffalo Chamber Vacuum Pack Machine	42		M5 x 16 Stainless Steel Screw
Buffalo Chamber Vacuum Pack Machine	43		Strut
Buffalo Chamber Vacuum Pack Machine	44		Insulating Strip for PCB
Buffalo Chamber Vacuum Pack Machine	45		PCB
Buffalo Chamber Vacuum Pack Machine	47		Vacuum Chamber
Buffalo Chamber Vacuum Pack Machine	48	AE930	Sealing Ring
Buffalo Chamber Vacuum Pack Machine	49		Lid
Buffalo Chamber Vacuum Pack Machine	50		Pressing Plate