



















Machine	Explode	Code	Description
Thor Freestanding Gas Griddle 36"	1	AF269	Dial
Thor Freestanding Gas Griddle 36"	2		Thor Badge
Thor Freestanding Gas Griddle 36"	3	AF293	Piezo Igniter
Thor Freestanding Gas Griddle 36"	4		Control Panel
Thor Freestanding Gas Griddle 36"	5		Control Rack
Thor Freestanding Gas Griddle 36"	6	AF602	Safety Valve
Thor Freestanding Gas Griddle 36"	7		Main Pipe Assembly (Left)
Thor Freestanding Gas Griddle 36"	8	AF300	Pilot Pipe Assembly (Left)
Thor Freestanding Gas Griddle 36"	9	AF285	Flame Device System (Injector not included)
Thor Freestanding Gas Griddle 36"	9	AF642	FDS Injector 0.25 (Propane)
Thor Freestanding Gas Griddle 36"	9	AF643	FDS Injector 0.45 (Nat)
Thor Freestanding Gas Griddle 36"	10		Griddle Plate Assembly
Thor Freestanding Gas Griddle 36"	11		Flue Assembly
Thor Freestanding Gas Griddle 36"	12		Copper Joints
Thor Freestanding Gas Griddle 36"	13	AF295	U Burner
Thor Freestanding Gas Griddle 36"	14		U Burner Fix
Thor Freestanding Gas Griddle 36"	15		Frame weld assy.
Thor Freestanding Gas Griddle 36"	16		Orifice Fix
Thor Freestanding Gas Griddle 36"	17	AF298	Pilot Pipe Assy.
Thor Freestanding Gas Griddle 36"	18		Heating Insulation Panel-side
Thor Freestanding Gas Griddle 36"	19		Heating Insulation
Thor Freestanding Gas Griddle 36"	20		Foot fix
Thor Freestanding Gas Griddle 36"	21		Orifice (LPG)
Thor Freestanding Gas Griddle 36"	21		Orifice (Nat)
Thor Freestanding Gas Griddle 36"	22		L connector
Thor Freestanding Gas Griddle 36"	23	AF299	Main Pipe Assy.
Thor Freestanding Gas Griddle 36"	24		Gas Stand
Thor Freestanding Gas Griddle 36"	25		Oil Tray Assy.