




Machine	Explode	Code	Description	Stocked Line
J193	1	AC217	Lid	✓
J193	2	n/a	Steamer	n/a
J193	3	AC202	Inner Pot	✓
J193	4	n/a	Element	n/a
J193	5	n/a	Casing	n/a
J193	6	AC198	Control Lever	✓
J193	7	AC195	Control Panel	✓
J193	8	AC206	Bottom Cover	✓
J193	n/a	AC192	Lid Handle	✓
J193	n/a	AC193	Heat Prevent Washer on Window	✓
J193	n/a	AC194	Handle	✓
J193	n/a	AC196	Indicating Pilot Cover (Red)	✓
J193	n/a	AC197	Indicating Pilot Cover (Yellow)	✓
J193	n/a	AC199	Support Leg	✓
J193	n/a	AC200	Scoop	✓
J193	n/a	AC201	Cooker Cap	✓
J193	n/a	AC203	Shroud	✓
J193	n/a	AC204	Keep Warm Pot	✓
J193	n/a	AC205	Bracket	✓
J193	n/a	AC207	Metal Ring in Base	✓
J193	n/a	AC208	Strap	✓
J193	n/a	AC209	Switch Lever Pillar	✓
J193	n/a	AC210	Heating Plate	✓
J193	n/a	AC211	Keep Warm Heater	✓
J193	n/a	AC212	Temperature Limiter	✓
J193	n/a	AC213	Indicating Board Bulb Plug Board	✓
J193	n/a	AC214	Thermal Fuse	✓
J193	n/a	AC215	Cord Set	✓
J193	n/a	AC216	Attachment Inlet	✓