













Machine	Explode	Code	Description
Ftp 94 mini cordless whisk	0702		HANDLE SCREW (1)
Ftp 94 mini cordless whisk	0908	AD513	NON-LOCKING SWITCH
Ftp 94 mini cordless whisk	1027	AD573	DYNAMIC LABEL
Ftp 94 mini cordless whisk	4022		HOLDER ASSEMBLY SCREWS
Ftp 94 mini cordless whisk	8317		BRACE SCREWS (4)
Ftp 94 mini cordless whisk	9401.1		LOWER HALF HANDLE (LABEL SIDE)
Ftp 94 mini cordless whisk	9402		UPPER HALF HANDLE
Ftp 94 mini cordless whisk	9404	AD569	CLIPS (2)
Ftp 94 mini cordless whisk	9416		BRACES (4)
Ftp 94 mini cordless whisk	9417		MOTOR & GEAR
Ftp 94 mini cordless whisk	9418		WHISK CONNECTION BOX W/ 3 RINGS
Ftp 94 mini cordless whisk	9420		MIDDLE GEAR & AXLE
Ftp 94 mini cordless whisk	9421		EQUIPPED OUTPUT SHAFT W/ 2 GEARS + 2 PINS
Ftp 94 mini cordless whisk	9422		HOLDER ASSEMBLY W/ SEALS & WASHER+D331
Ftp 94 mini cordless whisk	9424	AD547	WHISKS (2)
Ftp 94 mini cordless whisk	9431		COMPLETE HANDLE