





Machine	Explode	Code	Description
DB203 - Buffalo Double Fryer - 2x3Ltr	1	AD585	Indicator Light
DB203 - Buffalo Double Fryer - 2x3Ltr	2	AK361	Knob
DB203 - Buffalo Double Fryer - 2x3Ltr	3		Electrical Rear Plate Assembly
DB203 - Buffalo Double Fryer - 2x3Ltr	4	N117	Breaker
DB203 - Buffalo Double Fryer - 2x3Ltr	5	N116	Thermostat
DB203 - Buffalo Double Fryer - 2x3Ltr	6	AH342	Switch
DB203 - Buffalo Double Fryer - 2x3Ltr	7	N280	Heating Element
DB203 - Buffalo Double Fryer - 2x3Ltr	8	N282	Basket
DB203 - Buffalo Double Fryer - 2x3Ltr	9	N279	Oil Pan Assembly
DB203 - Buffalo Double Fryer - 2x3Ltr	10		Electrical Box Assy.
DB203 - Buffalo Double Fryer - 2x3Ltr	11	N287	Feet
DB203 - Buffalo Double Fryer - 2x3Ltr	12		Baffle Plate
DB203 - Buffalo Double Fryer - 2x3Ltr	13	AH040	Switch
DB203 - Buffalo Double Fryer - 2x3Ltr	14	AC841	Cover Assy
DB203 - Buffalo Double Fryer - 2x3Ltr	15		Handle