




Machine	Explode	Code	Description
GF489 Polar Slush Machine – 10 ltr	1		LED Light Holder
GF489 Polar Slush Machine – 10 ltr	2		LED Light
GF489 Polar Slush Machine – 10 ltr	3	AE921	Lid
GF489 Polar Slush Machine – 10 ltr	4	AE922	Bowl
GF489 Polar Slush Machine – 10 ltr	5		Tap Bracket
GF489 Polar Slush Machine – 10 ltr	6	AE920	Spring of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	7		Handle Pin of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	8		Handle of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	9		Top Panel
GF489 Polar Slush Machine – 10 ltr	10	AE920	Lever of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	11		Piston of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	12		Nozzle of Tap Assembly
GF489 Polar Slush Machine – 10 ltr	13		Frame
GF489 Polar Slush Machine – 10 ltr	14		Side Panel Bracket
GF489 Polar Slush Machine – 10 ltr	15		Front Panel Fixing
GF489 Polar Slush Machine – 10 ltr	16		Feet
GF489 Polar Slush Machine – 10 ltr	17		Side Panel Guard
GF489 Polar Slush Machine – 10 ltr	18		Left Side Panel
GF489 Polar Slush Machine – 10 ltr	19		Side Panel Runner
GF489 Polar Slush Machine – 10 ltr	20		Drainage Tube
GF489 Polar Slush Machine – 10 ltr	21		Front Panel
GF489 Polar Slush Machine – 10 ltr	22		Lid of Drip Tray
GF489 Polar Slush Machine – 10 ltr	23		Water Tray Overflow Indicator
GF489 Polar Slush Machine – 10 ltr	24		Drip Tray
GF489 Polar Slush Machine – 10 ltr	25		Seal of auger
GF489 Polar Slush Machine – 10 ltr	26		Auger
GF489 Polar Slush Machine – 10 ltr	27		Axle Seal
GF489 Polar Slush Machine – 10 ltr	28		Axle Washer
GF489 Polar Slush Machine – 10 ltr	29		Evaporator Seal
GF489 Polar Slush Machine – 10 ltr	30		Evaporator
GF489 Polar Slush Machine – 10 ltr	31		Evaporator Bracket
GF489 Polar Slush Machine – 10 ltr	32		Evaporator Back Brace
GF489 Polar Slush Machine – 10 ltr	33		Axle
GF489 Polar Slush Machine – 10 ltr	34		Axle Connector
GF489 Polar Slush Machine – 10 ltr	35		Evaporator Back Bracket
GF489 Polar Slush Machine – 10 ltr	36		Motor Position Adjustment Valve
GF489 Polar Slush Machine – 10 ltr	37	AE923	Gear Motor
GF489 Polar Slush Machine – 10 ltr	38		Micro Switch
GF489 Polar Slush Machine – 10 ltr	39		Back Panel
GF489 Polar Slush Machine – 10 ltr	40		Power Supply for LED & Temp. Controller
GF489 Polar Slush Machine – 10 ltr	41		Relay for Temp. Controller
GF489 Polar Slush Machine – 10 ltr	42		Control Panel
GF489 Polar Slush Machine – 10 ltr	43	AE924	Temperature Controller
GF489 Polar Slush Machine – 10 ltr	44	AE925	Sensor
GF489 Polar Slush Machine – 10 ltr	45		Right Side Panel
GF489 Polar Slush Machine – 10 ltr	46	AE926	Main Switch
GF489 Polar Slush Machine – 10 ltr	47	AE927	Small Switch

Exploded diagram and spare parts list

GF489

GF489 Polar Slush Machine – 10 ltr	48		Condenser
GF489 Polar Slush Machine – 10 ltr	49		Filter Drier
GF489 Polar Slush Machine – 10 ltr	50		Solenoid Valve
GF489 Polar Slush Machine – 10 ltr	51	AE928	Compressor
GF489 Polar Slush Machine – 10 ltr	52		Power Cord
GF489 Polar Slush Machine – 10 ltr	53	AE929	Compacitor