

HED240

Heated Display Unit



Troubleshooting Guide - With the appliance unplugged and cool.

Unit not working / dead	Check/replace the plug fuse.
	Check socket and ring main are working and switched on.
	Check power cord and plug for condition
	Check temperature setting dial
	Check lamp switches are set to the ON position
Temperature cannot be controlled	Thermostat may need to be replaced - contact approved service agent
Infrared lamps are not working	Check lamp switches are set to the correct position
	Check bulbs and installed correctly
	Bulb(s) may need to be replaced (not covered under warranty)
	Switch gear may need to be replaced
Indicator light is not illuminated	Power indicator light may need to be replaced
Base is heating	Contact approved service agent
Indicator light is illuminated	Check temperature setting dial
Base is not heating	Element may need replacing - contact approved service agent
	Thermostat may need to be replaced - contact approved service agent