



**Chefmaster Coffee Jug Hotplates
Instruction Manual**

Model -HEB087

Thank you for purchasing your Chefmaster Coffee Jug Hotplates. To make full use of the product please read this manual carefully before using the product and keep it safe for future reference.

Safety Tips

- If you find any damage when the product is unpacked, contact your Chefmaster supplier within 24 hours of receipt of goods.
- Always position the appliance on a flat stable surface.
- Plates become hot during operation - DO NOT TOUCH!
- This product is not designed to be used by persons with reduced physical or mental capabilities, lack of experience or knowledge, unless they are given suitable supervision, this includes children.
- DO NOT immerse the appliance in water or any other liquids.
- Always switch off and disconnect from the main power if not in use or before cleaning.

Pack of contents

Coffee jug hotplates

Instruction Manual

Operation



The two hotplates work independently of each other.

1. Remove the appliance from the packaging. Ensure that all protective plastic film and coating are removed thoroughly from all surfaces.
2. Connect the appliance to the mains power supply.
3. Place the coffee jug (s) on the hotplate(s).
4. Turn the relevant power switch to the On position (→).

Cleaning, Care & Maintenance

- Always turn off and disconnect the appliance from the power supply before cleaning.
- Use soapy water and a damp cloth to clean the exterior of the appliance.
- Dry thoroughly after cleaning.

Trouble shooting

Fault	Possible Cause	Solution
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call Chefmaster distributor or qualified technician
	Fuse in the plug has blown	Replace the plug fuse
	Power supply	Check power supply

Technical Information

HEB087 Chefmaster Coffee Jug Hotplates

Voltage 230V 50Hz

Power 120W (60W+60W)

Weight 1.6kg

Material Steel

Hot Plate Diameter 130mm

Dimensions 355mm x 180mm x 70mm (Lx W x H)

- Chefmaster Coffee Jug Hotplates is supplied with a 3 pin plug and lead with a 13 amp fuse
- Appliance must be earthed
- If in doubt contact a qualified electrician or your Chefmaster distributor

Disposal



Under WEEE regulations this product must not be disposed of as household waste. To prevent damage to the environment and humans this product must be disposed of in an approved and environmentally friendly recycling process. For more information on how to dispose of this correctly please contact your Chefmaster distributor or local authority responsible for waste disposal.

Compliance



All Chefmaster parts and products have under gone a stringent testing process to ensure that comply with all European standards and specifications. All Chefmaster products carry the CE approval symbol.