



# CLEANING GUIDE





To ensure the best performance and longevity of your CiBO+, **it must be cleaned daily and regularly deep cleaned.**

2 Deep clean as required using the heavy duty cleaner to remove the toughest carbon, grease and fat deposits.

The following instructions are for use with our CiBO Daily Oven Cleaner for daily use and CiBO Heavy Duty Oven Cleaner as required.



**FOR YOUR SAFETY YOU MUST** wear suitable PPE when using these cleaners.  

Scan me for the latest CiBO+ support videos



1

Press the cleaning icon and follow the on screen prompt to open door. Place a tea towel over the oven door as it could still be hot.



2

Wait for the oven to cooldown to 50 degrees.



3


The oven will prompt you to apply cleaner. Spray oven cleaner on cavity sides, back and base. **DO NOT** spray on the roof inside the CiBO+ as it may damage the catalytic convertor. Remove tea towel and spray inside oven door.



4

4


Press the green tick on the screen to confirm cleaner has been applied. Follow the on screen prompts to close the oven door, and leave to work for three minutes.





5


Agitate any stubborn deposits on the inside of the oven door with a non-metallic scourer. Wipe the inside of the oven door with a clean damp cloth.



5

6

Agitate any stubborn deposits on the cavity sides, back and base with a non-metallic scourer. Wipe out the oven with a clean damp cloth. Press the tick on screen to confirm the oven has been wiped.



7

Dry oven cavity and inside oven door with a paper towel.



6

8

Follow on screen prompt and spray CiBO Daily Oven Protect on the inside of the oven door, sides, back and base. Wipe any excess shield off with a paper towel.




9

Press tick to confirm CiBO+ Protect Oven Shield has been applied, and close door.



10

Remove filter below door and rinse, alternately put through dishwasher.





**CiBO**  
*family*

by **lincat**