
Exploded diagram and spare parts list (CU627)



Machine	Explode	Code	Description
Buffalo Large Countertop Griddle -Steel Plate	1	<b>~</b>	Apron
Buffalo Large Countertop Griddle -Steel Plate	2	<b>~</b>	Apron Front Plate
Buffalo Large Countertop Griddle -Steel Plate	3	<b>~</b>	Fuel Tank Track
Buffalo Large Countertop Griddle -Steel Plate	4	<b>~</b>	Plank Apron
Buffalo Large Countertop Griddle -Steel Plate	5	AS331	Heater
Buffalo Large Countertop Griddle -Steel Plate	6	<b>~</b>	Scraping Board
Buffalo Large Countertop Griddle -Steel Plate	7	<b>~</b>	Mica Insulating Board
Buffalo Large Countertop Griddle -Steel Plate	8	<b>~</b>	Cotton Sealing Board
Buffalo Large Countertop Griddle -Steel Plate	9	<b>~</b>	Pick The Front Plate
Buffalo Large Countertop Griddle -Steel Plate	10	AS348	Oil Box
Buffalo Large Countertop Griddle -Steel Plate	11	<b>~</b>	Bottom Sealing Plate
Buffalo Large Countertop Griddle -Steel Plate	12	AS338	Feet (set 4)
Buffalo Large Countertop Griddle -Steel Plate	13	<b>~</b>	Fixed Plate
Buffalo Large Countertop Griddle -Steel Plate	14	AS344	Knob
Buffalo Large Countertop Griddle -Steel Plate	15	<b>~</b>	Fixed Board
Buffalo Large Countertop Griddle -Steel Plate	16	AS333	Switch
Buffalo Large Countertop Griddle -Steel Plate	17	AS332	Indicator Light
Buffalo Large Countertop Griddle -Steel Plate	18	AS336	Hi-Limit
Buffalo Large Countertop Griddle -Steel Plate	19	AS326	Thermostat