

Exploded diagram and spare parts list


CD084







For machines with refrigerant R600a


[Click](#)








For machines with refrigerant R134a

[Click](#)



Machine	Explode	Code	Description
Polar REFRIGERATOR St/St - 600Ltr (UK)	1	AD037	Up Hinge
Polar REFRIGERATOR St/St - 600Ltr (UK)	2	AD027	Hook Of Lock
Polar REFRIGERATOR St/St - 600Ltr (UK)	4	AG193	Front Panel
Polar REFRIGERATOR St/St - 600Ltr (UK)	5	AD026	Hinge Axis
Polar REFRIGERATOR St/St - 600Ltr (UK)	6	AB354	Bushing
Polar REFRIGERATOR St/St - 600Ltr (UK)	7	AD028	Lock
Polar REFRIGERATOR St/St - 600Ltr (UK)	9	AD025	Gasket
Polar REFRIGERATOR St/St - 600Ltr (UK)	10		Door
Polar REFRIGERATOR St/St - 600Ltr (UK)	11	AD031	Shelf
Polar REFRIGERATOR St/St - 600Ltr (UK)	12	AD013	Down Hinge
Polar REFRIGERATOR St/St - 600Ltr (UK)	13	AD003	Bottom Shelf
Polar REFRIGERATOR St/St - 600Ltr (UK)	14	AD014	Evaporator Fixer
Polar REFRIGERATOR St/St - 600Ltr (UK)	15	AG093	Evaporator
Polar REFRIGERATOR St/St - 600Ltr (UK)	16		Body
Polar REFRIGERATOR St/St - 600Ltr (UK)	17	AB361	Foot
Polar REFRIGERATOR St/St - 600Ltr (UK)	18		Plug
Polar REFRIGERATOR St/St - 600Ltr (UK)	19	AA691	Junction Box
Polar REFRIGERATOR St/St - 600Ltr (UK)	20	AG014	Compressor
Polar REFRIGERATOR St/St - 600Ltr (UK)	21	AD035	Unite Board
Polar REFRIGERATOR St/St - 600Ltr (UK)	22	AB339	Condenser Fan
Polar REFRIGERATOR St/St - 600Ltr (UK)	23		Condenser Fan Support
Polar REFRIGERATOR St/St - 600Ltr (UK)	24	AD201	Condenser
Polar REFRIGERATOR St/St - 600Ltr (UK)	25	AD038	Water Box
Polar REFRIGERATOR St/St - 600Ltr (UK)	26		Unite Room Grills
Polar REFRIGERATOR St/St - 600Ltr (UK)	28	AF646	Circular Fan
Polar REFRIGERATOR St/St - 600Ltr (UK)	29		Circular Fan Support
Polar REFRIGERATOR St/St - 600Ltr (UK)	30	AA639	Sensor Fixed Clip
Polar REFRIGERATOR St/St - 600Ltr (UK)	31	AC614	Sensor
Polar REFRIGERATOR St/St - 600Ltr (UK)	32	AB363	Thermostat



Machine	Explode	Code	Description
Polar REFRIGERATOR St/St - 600Ltr (UK)	1	AD037	Up Hinge
Polar REFRIGERATOR St/St - 600Ltr (UK)	2	AD027	Hook Of Lock
Polar REFRIGERATOR St/St - 600Ltr (UK)	3		Thermostat Support
Polar REFRIGERATOR St/St - 600Ltr (UK)	4	AD341	Front Panel
Polar REFRIGERATOR St/St - 600Ltr (UK)	5	AD026	Hinge Axis
Polar REFRIGERATOR St/St - 600Ltr (UK)	6	AB354	Bushing
Polar REFRIGERATOR St/St - 600Ltr (UK)	7	AD028	Lock
Polar REFRIGERATOR St/St - 600Ltr (UK)	9	AD025	Gasket
Polar REFRIGERATOR St/St - 600Ltr (UK)	10		Door
Polar REFRIGERATOR St/St - 600Ltr (UK)	11	AD031	Shelf
Polar REFRIGERATOR St/St - 600Ltr (UK)	12	AD013	Down Hinge
Polar REFRIGERATOR St/St - 600Ltr (UK)	13	AD003	Bottom Shelf
Polar REFRIGERATOR St/St - 600Ltr (UK)	14	AD014	Evaporator Fixer
Polar REFRIGERATOR St/St - 600Ltr (UK)	15	AG093	Evaporator
Polar REFRIGERATOR St/St - 600Ltr (UK)	16		Body
Polar REFRIGERATOR St/St - 600Ltr (UK)	17	AB361	Foot
Polar REFRIGERATOR St/St - 600Ltr (UK)	18		Plug
Polar REFRIGERATOR St/St - 600Ltr (UK)	19	AA691	Junction Box
Polar REFRIGERATOR St/St - 600Ltr (UK)	20	AB865	Compressor
Polar REFRIGERATOR St/St - 600Ltr (UK)	21	AD035	Unite Board
Polar REFRIGERATOR St/St - 600Ltr (UK)	22	AB339	Condenser Fan
Polar REFRIGERATOR St/St - 600Ltr (UK)	23		Condenser Fan Support
Polar REFRIGERATOR St/St - 600Ltr (UK)	24	AD201	Condenser
Polar REFRIGERATOR St/St - 600Ltr (UK)	25	AD038	Water Box
Polar REFRIGERATOR St/St - 600Ltr (UK)	26		Unite Room Grills
Polar REFRIGERATOR St/St - 600Ltr (UK)	28	AF646	Circular Fan
Polar REFRIGERATOR St/St - 600Ltr (UK)	29		Circular Fan Support
Polar REFRIGERATOR St/St - 600Ltr (UK)	30	AA639	Sensor Fixed Clip
Polar REFRIGERATOR St/St - 600Ltr (UK)	31	AC614	Sensor
Polar REFRIGERATOR St/St - 600Ltr (UK)	32	AD033	Thermostat