




Machine	Explode	Code	Description
Buffalo Single Electric Fryer - 3Ltr	1		Apron
Buffalo Single Electric Fryer - 3Ltr	2		Apron Back Plate
Buffalo Single Electric Fryer - 3Ltr	3	AS337	Black Rubber Feet (set 4)
Buffalo Single Electric Fryer - 3Ltr	4		Foot Plate
Buffalo Single Electric Fryer - 3Ltr	5		Fretting Switch Roof
Buffalo Single Electric Fryer - 3Ltr	6		Dowel
Buffalo Single Electric Fryer - 3Ltr	7	AS339	1/3 GN Pan
Buffalo Single Electric Fryer - 3Ltr	8		Blasting Net Support Piece
Buffalo Single Electric Fryer - 3Ltr	9		Electric Box Hoarding
Buffalo Single Electric Fryer - 3Ltr	10		Side Panel for Electric Box
Buffalo Single Electric Fryer - 3Ltr	11		Side Panel
Buffalo Single Electric Fryer - 3Ltr	12		Electric Box Sealing Plate
Buffalo Single Electric Fryer - 3Ltr	13		Electric Heating Pipe
Buffalo Single Electric Fryer - 3Ltr	14	AS341	Travel Switch
Buffalo Single Electric Fryer - 3Ltr	15		Heater Guard Plate
Buffalo Single Electric Fryer - 3Ltr	16	AS342	Cover
Buffalo Single Electric Fryer - 3Ltr	17	AS333	Switch
Buffalo Single Electric Fryer - 3Ltr	18	AS332	Indicator Light
Buffalo Single Electric Fryer - 3Ltr	19	AS344	Knob
Buffalo Single Electric Fryer - 3Ltr	20	AS324	Handle
Buffalo Single Electric Fryer - 3Ltr	21		Rubber Sleeve
Buffalo Single Electric Fryer - 3Ltr	22	AS335	Hi-Limit / Temperature Limiter
Buffalo Single Electric Fryer - 3Ltr	23	AS327	EGO Thermostat
Buffalo Single Electric Fryer - 3Ltr	24	AS345	Basket