




Machine	Explode	Code	Description
DM065 - Vacuum Packaging Machine	1		lid elements (plastic lid, inner board, side board, seal wire, thermal overload)
DM065 - Vacuum Packaging Machine	2		Hi Temp Tape 10 x 356 mm
DM065 - Vacuum Packaging Machine	3	AC835	Silicone Tube 320 mm (press heater)
DM065 - Vacuum Packaging Machine	4		Switch Button (vacuum & seal)
DM065 - Vacuum Packaging Machine	5		Push Sp OD 6 x 22 x 0.6 (For Switch Button)
DM065 - Vacuum Packaging Machine	6		Vacuum Connector Auto (T)
DM065 - Vacuum Packaging Machine	8		Control board PCB
DM065 - Vacuum Packaging Machine	9		electric wire A
DM065 - Vacuum Packaging Machine	10		Motor/Pump elements (motor, pump)
DM065 - Vacuum Packaging Machine	11		electromagnetic valve
DM065 - Vacuum Packaging Machine	12		BTM Cover
DM065 - Vacuum Packaging Machine	13		Power Cord Cover
DM065 - Vacuum Packaging Machine	14		Rubber Foot OD 15.5 x 3 mm
DM065 - Vacuum Packaging Machine	15	AC835	Arm Foam 330 x 40 mm x 3 mm
DM065 - Vacuum Packaging Machine	16		Down Housing Foam 330 x 40 mmx 8.4 mm
DM065 - Vacuum Packaging Machine	17		Main body elements (main body, indicator piece)
DM065 - Vacuum Packaging Machine	18		Stop Piece For Arm
DM065 - Vacuum Packaging Machine	19		Vacuum Connector Auto (L)
DM065 - Vacuum Packaging Machine	20		Power supply PCB
DM065 - Vacuum Packaging Machine	21		electric wire B
DM065 - Vacuum Packaging Machine	22		Motor BD PCB
DM065 - Vacuum Packaging Machine	23		Clip Spring
DM065 - Vacuum Packaging Machine	24		Clip (Left)