

## Chefmaster Fly Killers Instruction Manual

#### <u>Model</u>

HEA780 – Aluminum 50m<sup>2</sup> Coverage HEA325 - Aluminum 50m<sup>2</sup> Coverage HEA781 – Stainless Steel 50m<sup>2</sup> Coverage HEA782 – Aluminum 100m<sup>2</sup> Coverage HEA783 – Stainless Steel 100m<sup>2</sup> Coverage HEA785 – Stainless Steel 150m<sup>2</sup> Coverage Thank you for purchasing your Chefmaster Fly Killer. To make full use of the product please read this manual carefully before using the product and keep it safe for future reference.

#### Safety Tips

- If you find any damage when the product is unpacked, contact your Chefmaster supplier within 24 hours of receipt of goods
- Repairs should always be carried out by a qualified technician
- Do not use this product outside
- Install out of reach of Children
- Install at least 1m away from food preparation areas
- Do not use near flammable objects
- Always switch off and unplug the unit before cleaning
- If the power cord becomes damaged it must be replaced by a qualified technician
- This product is not designed to be used by persons with reduced physical or mental capabilities, lack of experience or knowledge, unless they are given suitable supervision, this includes children.
- This product is designed for indoor use only.



#### Pack Contents

- 1 x Chefmaster Fly Killer
- 1 x Hanging chain

#### Before Use

- Remove all packaging including all protective plastic, from your Chefmaster Fly Killer
- For best results install your fly killer in the darkest part of the room, 1m way from any food preparation areas

#### **Operation**

- Ensure the fly killer is plugged in and the power is on
- The light will then come on and the grid will be electrically charged

#### Cleaning & Maintenance

- Before cleaning disconnect the fly killer from the electricity supply.
- Clean the collection tray with soapy warm water regularly

• DO NOT submerge the fly killer in water or use water sprays to clean it

#### Changing the Bulb

- Unscrew the 2 screws on the top of the outer metal grid
- The grid will then open downwards
- Remove bulb and replace
- Replace the out metal grid into its original position

#### **Troubleshooting**

Fault	Possible Cause	Solution
Unit is not working	The unit is not switched	Check the unit is plugged in
	on	and switched on
	The plug or lead are	Contact your Chefmaster
	damaged	distributor
	The fuse has blown	Replace the fuse
	Bulb is not working	Replace the bulb

#### Transportation and Storage

Please handle your fly killer with care to prevent any damage to the unit and internal parts. The fly killer should be stored somewhere which is ventilation and non-corrosive gas.

Do not store any flammable objects near the equipment.

#### **Technical Information**

HEA780 – Aluminum 50m<sup>2</sup> Coverage Voltage ~230v 50/60Hz Power 11watt Weight 1.95kg Dimensions 340 x 100 x 265mm

HEA325 - Aluminum 50m<sup>2</sup> Coverage

Voltage ~230v 50/60Hz Power 11watt Weight 1.95kg Dimensions 340 x 100 x 265mm

#### HEA781 – Stainless Steel 50m² Coverage Voltage ~230v 50/60Hz

Power 11watt

Weight 2.5kg Dimensions 390 x 115 x 265mm

#### HEA782 – Aluminum 100m<sup>2</sup> Coverage

Voltage ~230v 50/60Hz Power 22watt Weight 2.2kg Dimensions 335 x 100 x 265mm

#### HEA783 – Stainless Steel 100m<sup>2</sup> Coverage

Voltage ~230v 50/60Hz Power 22watt Weight 2.6kg Dimensions 395 x 115 x 265mm

#### HEA784 – Aluminum 150m<sup>2</sup> Coverage

Voltage ~230v 50/60Hz Power 33watt Weight 2.7kg Dimensions 490 x 100 x 265mm

#### HEA785 – Stainless Steel 150m<sup>2</sup> Coverage

Voltage ~230v 50/60Hz Power 33watt Weight 3.3kg Dimensions 550 x 115 x 265mm

- Chefmaster fly killer is supplied with a 3 pin plug and lead with a 13 amp fuse
- Appliance must be earthed
- If in doubt contact a qualified electrician or your Chefmaster distributor

#### Disposal



Under WEEE regulations this product must not be disposed of as household waste. To prevent damage to the environment and humans this product must be disposed of in an approved and environmentally friendly recycling process. For more information on how to dispose of this correctly please contact your Chefmaster distributor or local authority responsible for waste disposal.

### **Compliance**

# CE

All Chefmaster parts and products have under gone a stringent testing process to ensure that comply with all European standards and specifications. All Chefmaster products carry the CE approval symbol.