
















VOGUE

Stainless Steel Wall Cupboard: FU580/FU581/FU582/FU583:






Assembly Instructions

Packed parts








Part description			Qty.	Part description			Qty.
A	Top panel		1	H	Middle shelf		1
B	Back panel		1	I	Support for middle shelf		4
C	Bottom panel		1	J	Screw for top/bottom panel		8
D	Left panel		1	K	Connecting rod		FU580 x 10 FU581 x 12 FU582 x 14 FU583 x 14
E	Right panel		1				
F	Outer door		1	L	Wall mounting plate		1
G	Inner door		1	Assembly tool			



Manual size: A4 folded into A5



Manual size: A4 folded into A5



Cleaning, Care & Maintenance

- Before using for the first time the cupboard should be cleaned thoroughly.
- Clean the cupboard regularly using a cleaning agent suitable for use with stainless steel.
- Always remove cleaning agent residue. This can discolour the surface of the cupboard.
- Never leave the surfaces damp as this can cause discolouration.



UK		Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom
Eire	+44 (0)845 146 2887	Unit 9003, Blarney Business Park, Blarney Co. Cork, Ireland
NL	040 - 2628080	
FR	01 60 34 28 80	
BE-NL	0800-29129	

BE-FR	0800-29229	
DE	0800 - 1860806	
ES	901-100 133	
AU	1300 225 960	15 Badgally Road, Campbelltown, 2560, NSW, Australia

FU580 to FU583_ML_A5_v1_2024/02/01