

HEA841

Electric Carving Knife



Troubleshooting Guide - With the appliance unplugged

Personal Protective Equipment	Wear suitable PPE when handling this appliance for troubleshooting
Unit not working / dead	Check/replace the plug fuse.
	Check socket and ring main are working and switched on.
	Check power cord and plug for condition
Unit is getting hot	These knives are designed for light duty periodic use only.
	Allow unit to cool and restart
	Too much forces is being, overworking the motor
	Product is not suitable for cutting with an electric knife (i.e. frozen)