



E3840 - SPARES - CONTROL PANEL

ITEM	DESCRIPTION	SPARES No
1	CONTROL PANEL ASSEMBLY	731390000
1.1	RED NEON	730962010
1.2	AMBER NEON	730962040
1.3	CONTROL KNOB C/W STOP	731350001
1.4	CONTROLLER	731350002




E3840 - SPARES - MAIN BODY




ITEM	DESCRIPTION	SPARES No
1	HOB PAN ASSEMBLY C/W DRAIN VALVE	731540000
2	L/H OUTER SIDE	731540001
3	R/H OUTER SIDE	731540002
4	DOOR ASSEMBLY	731540003
5	TOP DOOR HINGE	731390005
6	BOTTOM DOOR HINGE	731540004
7	DRAIN HANDLE	731350007
8	DRAIN HANDLE FLAP	731350008
9	L/H BUCKET RUNNER	731350009
10	R/H BUCKET RUNNER (NOT SHOWN)	731350010
11	ELEMENT GUARD	731460001
12	CHIP BASKET	536430126
13	DRAIN PROD / LIFTING TOOL	731350012
14	4 OFF ADJUSTABLE FEET INCL FIXINGS	531886613
15	4 OFF CASRORS INCL FIXINGS (NOT SHOWN)	535400209
16	DUST COVER	731540005

E3840 - SPARES - ELECTRICS




DETAIL A
SCALE 1 : 2

ITEM	DESCRIPTION	UNIT	SPARES No
1	RELAY BASE 95.83.3		536430019
2	RELAY 240V SINGLE POLE C/O		535770128
3	FUSE HOLDER		734310510
4	2 AMP ANTI-SURGE FUSE		734243006
5	5 AMP ANTI-SURGE FUSE	FILTER ONLY	536430009
6	BALLAST RESISTOR		731540006
7	MOMENTARY PUSH-BUTTON SWITCH		731460006
8	ROCKER SWITCH		731430011
9	LAMP ENCLOSURE		731460008
10	LAMP/SOUNDER AMBER		731460007
11	CABLE GLAND C/W NUT		731350026
12	CONTACTOR		734510010
13	PUMP TIMER	FILTER ONLY	536470007
14	MAINS TERMINAL BLOCK		731000006
NOT SHOWN			
15	MAIN WIRING LOOM	E3840F	731460016
16	MAIN WIRING LOOM	E3840	731460017
17	MAINS INLET CABLE		731350046



REAR VIEW, CONTROL BOX


E3840 - SPARES - ELEMENT BOX



ITEM	DESCRIPTION	SPARES No
1	ELEMENT BOX LID GASKET	731460002
2	TILT SWITCH	731460003
3	PILLAR TO ELEMENT BOX GASKET	731460004
4	HOB TO SUPPORT PILLAR GASKET	731460010
5	ELEMENT BOX LID / BASKET HANGER	731460005
6	THERMISTOR PROBE	731460018
7	SAFETY STAT C/W FITINGS	731421060
8	ELEMENT BOX ASSEMBLY (BOX ONLY)	731460009
9	ELEMENT 10 kW C/W GASKET	731460012
9.1	ELEMENT GASKET	731350023
10	ELEMENT 7.5 kW C/W GASKET	731460013



E3840 - SPARES - FILTRATION



ITEM	DESCRIPTION	SPARES No
1	OIL CONTAINER ASSEMBLY	731350029
1.1	OIL CONTAINER HANDLE	731350030
2	OIL CONTAINER CARRIER	535770028
3	FINE MESH FILTER	737101159
4	FINE MESH FILTER WIRE SUPPORT	737101143
5	BASKET FILTER	535770032
6	SUCTION PIPE FILTER	731350032
7	OIL PICK UP PIPE	731350052
8	OIL PUMP C/W SCREWS	535770077
9	OIL PUMP OUTLET PIPE C/W OLIVES	731460011
10	OIL RETURN PIPE COUPLING	731350071
11	OIL RETURN ELBOW 1/2" BSPP-15MM	731540007
12	OIL RETURN PIPE GASKET	731350042
13	OIL RETURN 1/2" BSPP-12MM MALE STUD COUPLING	731540008
14	OIL RETURN PIPE	731540009