HEA776 / HEA777 / HED232 / HED233



Soup Kettle

Troubleshooting Guide - With the appliance unplugged and cool.	
Unit not working / dead	Check/replace the plug fuse.
	Check socket and ring main are working and switched on.
	Check the cord and plug for condition
	Check the dial is set to correct temperature
Power indicator light is not on	Perform above checks
Unit is on but not heating	Check thermostat temperature selection
	Thermostat may need replacing - contact approved service agent

If fault persists, please contact your approved maintenance and repair contractor.