











































| Machine | Explode | Code | Description |
|---|---------|---|-----------------------------|
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 1 |  | Lid Reservoir |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 2 |  | Grill Reservoir |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 3 |  | Reservoir |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 4 |  | Upper Frame |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 5 |  | Indicate Panel |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 6 |  | Indication Lamp |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 7 |  | Power Switch Twin |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 7 |  | Power Switch Single |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 8 |  | Sprinkler |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 9 |  | Sprinkler Cover |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 10 |  | Sealing Washer of Sprinkler |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 11 |  | Sprinkler Distributor |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 12 |  | Support Frame |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 13 |  | Warming Plate |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 14 |  | Mica Warmer Plate |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 15 |  | Base Frame |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 16 |  | Lower Panel |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 17 |  | Bottom Heel |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 18 |  | Float Switch |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 19 |  | Sealing Washer of Float |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 20 |  | Spillway tube reservoir |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 21 |  | Mist partition |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 22 |  | Silicon pipe water in |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 23 |  | Thermostat |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 24 |  | Lid boiler |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 25 |  | Sealing washer of heater |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 26 |  | Manual reset |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 27 |  | Heating element |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 28 |  | Sealing washer of boiler |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 29 |  | Manual reset thermostat |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 30 |  | Boiler tank |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 31 |  | Silicon pipe water out |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 32 |  | Rear frame |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 33 |  | Body frame |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 34 |  | Relay |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 35 |  | Relay holder |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 36 |  | Power cable & cord |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 37 |  | Power cable Protector |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 38 |  | Bottom cover |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 39 |  | Fever partition |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 40 |  | s/s filter pan |
| DN487 Buffalo Coffee Machine St/St - 2Ltr | 41 |  | Filter support |