




Machine	Explode	Code	Description
GE959 - Polar Portable Air Conditioning Unit	1	AL240	Castor (set 4)
GE959 - Polar Portable Air Conditioning Unit	2		Base Pan
GE959 - Polar Portable Air Conditioning Unit	3		Water Wheel
GE959 - Polar Portable Air Conditioning Unit	4	AM321	Water Motor
GE959 - Polar Portable Air Conditioning Unit	5		Main Bracket
GE959 - Polar Portable Air Conditioning Unit	6		Bolt
GE959 - Polar Portable Air Conditioning Unit	7		Flat Gasket
GE959 - Polar Portable Air Conditioning Unit	8		Compressor Pads
GE959 - Polar Portable Air Conditioning Unit	9		Compressor Sleeve
GE959 - Polar Portable Air Conditioning Unit	10		Nut
GE959 - Polar Portable Air Conditioning Unit	11		The Inlet Pipe of The Condenser
GE959 - Polar Portable Air Conditioning Unit	12		Delivery Tube
GE959 - Polar Portable Air Conditioning Unit	13		Insulated Pipe
GE959 - Polar Portable Air Conditioning Unit	14		Suction Tube
GE959 - Polar Portable Air Conditioning Unit	15		The Outlet Pipe of The Evaporator Tube
GE959 - Polar Portable Air Conditioning Unit	16	AT676	Four Way Valve
GE959 - Polar Portable Air Conditioning Unit	17		Back Cover
GE959 - Polar Portable Air Conditioning Unit	18		Lower Filter Frame A
GE959 - Polar Portable Air Conditioning Unit	19		Lower Filter Frame B
GE959 - Polar Portable Air Conditioning Unit	20	AP904	Lower Rubber Plug
GE959 - Polar Portable Air Conditioning Unit	21		Wrapping Post
GE959 - Polar Portable Air Conditioning Unit	22	AP686	Hose Inlet
GE959 - Polar Portable Air Conditioning Unit	23	AP905	Upper Rubber Plug
GE959 - Polar Portable Air Conditioning Unit	24		Upper Filter Frame
GE959 - Polar Portable Air Conditioning Unit	25		Plug Hole Piece B
GE959 - Polar Portable Air Conditioning Unit	26	AL241	Gear Seat
GE959 - Polar Portable Air Conditioning Unit	27		Driven Gear
GE959 - Polar Portable Air Conditioning Unit	28		Display PCB Cover
GE959 - Polar Portable Air Conditioning Unit	29	AM322	Display PCB
GE959 - Polar Portable Air Conditioning Unit	30		Air Outlet Frame
GE959 - Polar Portable Air Conditioning Unit	31		Sleeve Pipe
GE959 - Polar Portable Air Conditioning Unit	32		Top Cover
GE959 - Polar Portable Air Conditioning Unit	33		Top Cover Ring
GE959 - Polar Portable Air Conditioning Unit	34		Horizontal Guide Bar B
GE959 - Polar Portable Air Conditioning Unit	35		Horizontal Guide Bar A
GE959 - Polar Portable Air Conditioning Unit	36		Facial Mask
GE959 - Polar Portable Air Conditioning Unit	37	AL242	Driving Gear
GE959 - Polar Portable Air Conditioning Unit	38	AM323	Stepper Motor
GE959 - Polar Portable Air Conditioning Unit	39		Plug Hole Piece A
GE959 - Polar Portable Air Conditioning Unit	40		Evaporator
GE959 - Polar Portable Air Conditioning Unit	41		Upper Air Duct
GE959 - Polar Portable Air Conditioning Unit	42	AL243	Upper Fan Wheel

Machine	Explode	Code	Description
GE959 - Polar Portable Air Conditioning Unit	43		Wire Netting
GE959 - Polar Portable Air Conditioning Unit	44		Electric Box
GE959 - Polar Portable Air Conditioning Unit	45	AM324	Main PCB
GE959 - Polar Portable Air Conditioning Unit	46	AM325	Motor Capacitor
GE959 - Polar Portable Air Conditioning Unit	47		Electric Box Cover
GE959 - Polar Portable Air Conditioning Unit	48		Capacitor Card
GE959 - Polar Portable Air Conditioning Unit	49		Compressor Capacitor
GE959 - Polar Portable Air Conditioning Unit	50		Ground Wire Support
GE959 - Polar Portable Air Conditioning Unit	51	AL244	Upper Motor
GE959 - Polar Portable Air Conditioning Unit	52		Upper Air Duct Cover
GE959 - Polar Portable Air Conditioning Unit	53		Capillary
GE959 - Polar Portable Air Conditioning Unit	54	AL245	Water Pan
GE959 - Polar Portable Air Conditioning Unit	55	AM326	Compressor (R290)
GE959 - Polar Portable Air Conditioning Unit	56	AM327	Floater Switch
GE959 - Polar Portable Air Conditioning Unit	57		Condenser
GE959 - Polar Portable Air Conditioning Unit	58		Lower Air Duct
GE959 - Polar Portable Air Conditioning Unit	59	AM328	Lower Motor
GE959 - Polar Portable Air Conditioning Unit	60	AP618	Lower Fan Wheel
GE959 - Polar Portable Air Conditioning Unit	61		Lower Air Duct Cover
GE959 - Polar Portable Air Conditioning Unit	62		Line Cord
GE959 - Polar Portable Air Conditioning Unit	63	AM329	Front Display PCB
GE959 - Polar Portable Air Conditioning Unit	64		Front Cover
GE959 - Polar Portable Air Conditioning Unit	65		Front Cover Ring
GE959 - Polar Portable Air Conditioning Unit	66		Front Facial Mask
GE959 - Polar Portable Air Conditioning Unit	67		Power Cord
GE959 - Polar Portable Air Conditioning Unit	68		Compressor Wire
GE959 - Polar Portable Air Conditioning Unit	69		Compressor Capacitance Wire
GE959 - Polar Portable Air Conditioning Unit	70		Compressor Grounding Wire
GE959 - Polar Portable Air Conditioning Unit	71	AM330	Defrosting Temperature Sensor
GE959 - Polar Portable Air Conditioning Unit	72	AM331	Environmental Temperature Sensor
GE959 - Polar Portable Air Conditioning Unit	N/A	AP663	Drain Pipe
GE959 - Polar Portable Air Conditioning Unit	N/A	AP687	Hose Outlet-accessories
GE959 - Polar Portable Air Conditioning Unit	N/A	AP664	Exhaust Hose-accessories
GE959 - Polar Portable Air Conditioning Unit	N/A	AL224	Remote Control-accessories
GE959 - Polar Portable Air Conditioning Unit	N/A	AP906	Slide Bar/Window Kits-accessories