

Installation, Operating and Servicing Instructions

Silverlink 600 Heated and Ambient Pedestals CC3, CC4, CC6, CC7, CN3, CN4, CN6, CN7, HC3, HC4, HC6, HC7, HCL3, HCL4, HCL6, HCL7, HCL9.

Please make a note of your product details for future use:

Date Purchased:

Model Number:

Serial Number:

Dealer:

SILVERLINK 600

CONTENTS

Important Information	2
Warnings and Precautions	3
Technical Data	3
Checklist of Enclosures	4
Installation and Commissioning	4-5
Operating Instructions	5-6
Cleaning	6
Servicing, Maintenance and Component Replacement	6
Fault Finding	6
Spare Parts List	7
Accessories	7
Service Information and Guarantee	8

IMPORTANT INFORMATION



Read these instructions carefully before using this product, paying particular attention to all sections that carry warning symbols, caution symbols and notices. Ensure that these are understood at all times.



WARNING!

This symbol is used whenever there is a risk of personal injury.



CAUTION!

This symbol is used whenever there is a risk of damaging your Lincat product.



NOTE:

This symbol is used to provide additional information, hints and tips.

KEEP THIS MANUAL FOR FUTURE REFERENCE

WARNINGS AND PRECAUTIONS



This appliance must be installed, commissioned and serviced by a qualified person in accordance with national and local regulations in force in the country of installation.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person.

Ensure that the plug/socket is accessible at all times.

Strip plastic coating and clean the appliance before use.

During operation parts may become hot - avoid accidental contact.

Disconnect this appliance before servicing, maintenance or cleaning.

TECHNICAL DATA

Model	Height (mm) - adjustable	Width (mm)	Depth (mm)	Weight (kg)
CC3		300		14
CC4		450	600	18
CC6		600	800	22
CC7		750		26
CN3		300		11
CN4	650 - 670 650 - 685	450	567	14
CN6		600	307	17
CN7		750		20
HC3		300		17
HC4		450		21
HC6		600		25
HC7		750		30
HCL3		300	600	18
HCL4		450		22
HCL6		600		26
HCL7		750		30
HCL9		900		34

CHECK LIST OF ENCLOSURES

Warranty card	
Instructions manual	
Shelf	
Feet kit	

INSTALLATION AND COMMISSIONING

For Heated models:

This appliance must be earthed.



An equipotential bonding terminal is provided to allow cross bonding with other equipment.




Fig 1

If replacing the plug connect the terminals as follows:

Green and Yellow wire Earth E
Blue wire Neutral N
Brown wire Live L

Install this appliance on a level surface ensuring all vents are unobstructed. Any partitions, walls or furniture must be of non-combustible material. Minimum distances A 50mm B 500mm – see Fig 1.

This appliance is fitted with a moulded plug and lead ready to be connected to an earthed socket.

Screw the legs/feet provided into the base and adjust until level.

Power ratings

Model	Power (kW)	
CC3	-	
CC4	-	
CC6	-	
CC7	-	
CN3	-	
CN4	-	
CN6	-	
CN7	-	
HC3	0.25	
HC4	0.5	
HC6	0.5	
HC7	0.5	
HCL3	0.25	
HCL4	0.5	
HCL6	0.5	
HCL7	0.75	
HCL9	1.0	

OPERATING INSTRUCTIONS

Only qualified or trained personnel should use this appliance.

Heated Pedestals

Connect to the supply – the green switch will illuminate.

Press switch to 'On' and the appliance will heat up and then maintain the temperature at the factory set level.

Heated pedestals are designed for warming and holding plates and crockery. They operate at temperatures below the requirements of the Food Safety Regulations and are not intended for holding food.

Evenly distribute items and do not exceed the recommended weight per shelf as given in the table below.

Model width	Maximum weight per shelf (kg)	
300	30	
450	45	
600	60	
750	75	
900	90	

Additional shelves up to a total of 3 may be added (see accessories), however this may reduce the performance within the upper section of the appliance.

CLEANING



Do not use a water jet or steam cleaner, and do not immerse this appliance.

Clean all panels with warm water and mild detergent, do not use abrasive materials. Dry with a soft cloth.

SERVICING, MAINTENANCE AND COMPONENT REPLACEMENT

All servicing, maintenance and component replacement on these appliances should be carried out by one of our recommended service engineers.

FAULT FINDING

Please refer to the Service Helpdesk number on the final page of this manual.

SPARE PARTS LIST

Part Number	Description	Used on
EL214	Element – 250W	HC3, HCL3
EL216	Element – 500W	HC4, HC6, HC7, HCL4, HCL6, HCL9 (x 2)
EL219	Element – 750W	HCL7
FE10	Adjustable foot	CC, CN, HC models
FE29	Adjustable leg	HCL models
HA73	Door handle	
HI24	Door hinge	All door models
HI25	Hinge plate	
PL201	Plug & lead	
SW66	Switch	All heated models
TH75	Thermostat	

ACCESSORIES

Part Number	Description	Used on
PSH3		300 models
PSH4		450 models
PSH6	Shelf	600 models
PSH7		750 models
PSH9		900 models

SERVICE INFORMATION

For help with the installation, maintenance and use of your **Lincat** equipment, please contact our service department:

T UK: 01522 875520

For non-UK customers, please contact your local Lincat dealer

All service work, other than routine cleaning should be carried out by one of our authorised service agents. We cannot accept responsibility for work carried out by other persons.

To ensure your service enquiry is handled as efficiently as possible, please tell us:

- Brief details of the problem
- Product code
- Type number

All available on serial plate

Serial number

Lincat reserve the right to carry out any work under warranty, given reasonable access to the appliance, during normal working hours, Monday to Friday, 08:30 to 17:00.

GUARANTEE

This unit carries a comprehensive UK mainland 2 year warranty. The guarantee is in addition to, and does not diminish your statutory or legal rights.

The guarantee does not cover:

- Accidental damage, misuse or use not in accordance with the manufacturer's instructions
- Consumable items (such as filters, glass, bulbs, slot toaster elements and door seals.)
- Damage due to incorrect installation, modification, unauthorised service work or damage due to scale, food debris build-up, etc.

The manufacturer disclaims any liability for incidental, or consequential damages. Attendance is based on reasonable access to the appliance to allow the authorised technician to carry out the warranty work.

Service calls to equipment under warranty will be carried out in accordance with the conditions of sale. Unless otherwise specified, a maximum of 15 minutes of administrative time, not spent directly carrying out servicing work, is provided for within the warranty. Any requirement for staff attending the call to spend greater time than 15 minutes due to administrative requirements, such as on health and safety risk assessments, will be chargeable at the prevailing rate.