



Installation, Operating and Servicing Instructions

Opus 800 Pedestals
OA8970, OA8971, OA8972, OA8973,
OA8974

Please make a note of your product details for
future use:

Date Purchased: _____

Model Number: _____

Serial Number: _____

Dealer: _____

Opus **800**

CONTENTS

Important Information	2
Warnings and Precautions	3
Technical Data	3
Checklist of Enclosures	3
Installation and Commissioning	4
Cleaning	5
Servicing, Maintenance and Component Replacement	5
Fault Finding	5
Spare Parts List	5
Service Information and Guarantee	6

IMPORTANT INFORMATION



Read these instructions carefully before using this product, paying particular attention to all sections that carry warning symbols, caution symbols and notices. Ensure that these are understood at all times.




WARNING!

This symbol is used whenever there is a risk of personal injury.



CAUTION!

This symbol is used whenever there is a risk of damaging your Lincat product.



NOTE:

This symbol is used to provide additional information, hints and tips.

KEEP THIS MANUAL FOR FUTURE REFERENCE

WARNINGS AND PRECAUTIONS

Strip plastic coating and clean the pedestal before use.



Prior to connecting a counter top unit to a pedestal, a manual handling assessment should be conducted

TECHNICAL DATA

Model	Width (mm)	Height (mm) - adjustable	Depth (mm)
OA8970	300	650 - 670	690
OA8971	400		
OA8972	600		
OA8974	800		
OA8973	900		

CHECK LIST OF ENCLOSURES

Warranty card
Instructions manual
Fasteners
Leg kit

INSTALLATION AND COMMISSIONING



An equipotential bonding terminal is provided to allow cross bonding with other equipment.

Remove all protective coatings before installation.
Check for level and rectify by adjusting the legs using the spanner provided.

Connecting Appliances

To secure a countertop appliance to a pedestal, remove the legs from the counter top unit. Position the counter top onto the pedestal, aligning the holes to allow fastening.

Fasten using the screws and washers provided in all four corners (See fig 1).




Fig 1.

CLEANING

Clean all panels with warm water and mild detergent do not use abrasive materials. Dry with a soft cloth.

SERVICING, MAINTENANCE AND COMPONENT REPLACEMENT

All servicing, maintenance and component replacement on these appliances should be carried out by one of our recommended service engineers.

FAULT FINDING

Please refer to the Service Helpdesk number on the final page of this manual.

SPARE PARTS LIST

Part Number	Description
LE37	Adjustable Leg
HA73	Handle
SP56	Spanner

SERVICE INFORMATION

For help with the installation, maintenance and use of your **Lincat** equipment, please contact our service department:

☎ UK: 01522 875520

For non-UK customers, please contact your local Lincat dealer

All service work, other than routine cleaning should be carried out by one of our authorised service agents. We cannot accept responsibility for work carried out by other persons.

To ensure your service enquiry is handled as efficiently as possible, please tell us:

- Brief details of the problem
 - Product code
 - Type number
 - Serial number
- } All available on serial plate

Lincat reserve the right to carry out any work under warranty, given reasonable access to the appliance, during normal working hours, Monday to Friday, 08:30 to 17:00.

GUARANTEE

This unit carries a comprehensive UK mainland 2 year warranty. The guarantee is in addition to, and does not diminish your statutory or legal rights.

The guarantee does not cover:

- Accidental damage, misuse or use not in accordance with the manufacturer's instructions
- Consumable items (such as filters, glass, bulbs, slot toaster elements and door seals.)
- Damage due to incorrect installation, modification, unauthorised service work or damage due to scale, food debris build-up, etc.

The manufacturer disclaims any liability for incidental, or consequential damages. Attendance is based on reasonable access to the appliance to allow the authorised technician to carry out the warranty work.

Service calls to equipment under warranty will be carried out in accordance with the conditions of sale. Unless otherwise specified, a maximum of 15 minutes of administrative time, not spent directly carrying out servicing work, is provided for within the warranty. Any requirement for staff attending the call to spend greater time

than 15 minutes due to administrative requirements, such as on health and safety risk assessments, will be chargeable at the prevailing rate.