



HEA130 20 Tier GN Trolley Assembly Instructions

Assembly

- 1. Attach the six cross members to one of the side frames, using six of the screws supplied.
- 2. Lay this side frame on floor with the cross members pointing upwards.
- 3. Carefully position the second side frame on top of the cross members. Attach using the remaing screws.
- 4. With the assembled frames still on their side, screw the covers and castors into frames.
- * Braked castors should be at the front of the trolley.

Safety Tips

- DO NOT stand or climb on the trolley.
- o DO NOT drop heavy items on the trolley.
- o DO NOT place heavier items on the top of the trolley than on the bottom.

Cleaning

- o Clean the trolley using warm soapy water.
- o Dry thoroughly after cleaning

Parts (check before assembly)

<u>ITEM</u>	<u>QUANTITY</u>
Side frames, Castors, Castors with brakes	2 pieces each
Cross members	6 pieces
Castor covers	4 pieces
Screws	12 pieces
Нех Кеу	2 pieces (large x 1, small x 1)
Spanner	1 piece

Max. load: 15 kg per shelf, 100 kg overall